

# Classnet Computer Supervisory System

**F1**.....Preset: From Master to All. Press “From” to cancel.

**F2**.....Preset: Darken All Screens, Disable All Keyboards. Press “Dark” to cancel.

**F3**.....Not Preset—Make it what you want.

**F4**.....Not Preset—Make it what you want.

## **To Send Teacher’s Screen to one student:**

1. Press “From”.
2. Press “Master”.
3. Press Student number. (02,10, 24, etc.) It is always a 2-digit number. All numbers under 10 start with 0.
4. Press “Enter”.
5. To cancel, press “From”.

## **To Send Student’s Screen to Teacher:**

1. Press “From”.
2. Press Student number. (02, 12, 23, etc.)
3. Press “Master”.
4. Press “Enter”.
5. To cancel, press “From”.

## **To Send Student’s Screen to Class (as an example):**

1. Press “From”.
2. Press Student number. (02, 12, 23, etc.)
3. Press “All”.
4. Press “Enter”.
5. To cancel, press “From”.

## **To Send Teacher’s Screen to Class and give Keyboard/Mouse control to a student:**

1. Press “F1” (Master to All)
2. Choose student for keyboard/mouse control of Teacher’s computer.
3. Press “KB”.
4. Press Student number.
5. Press “Enter”. Student can now control your computer; rest of the class watches.
6. To cancel Keyboard/Mouse control, press “KB”. You have control back.
7. To choose a different student, repeat steps 2-5.
8. To completely cancel, press “KB”, then “From”.

**To Bring Student's Screen AND keyboard/Mouse control to Teacher:**

1. Press "KB".
2. Select Student number (02,18, 24, etc.)
3. Press "Enter". The Student's screen is brought to the Teacher's screen along with Keyboard/Mouse control. The student has no control over his computer.
4. To give control back to student, press "KB".

**Placing Students into Groups:**

1. Press "Group".
2. Choose Group number. (You can set up to 8 different groups from 0 – 7. Group 8 is the even numbered students. Group 9 is the odd numbered students.)
3. Place the students in the group (01, 02, 07, etc.) If you make a mistake, hit clear. If you want to clear all of them, press "Clear" and All".
4. Press "Enter". The students will stay in the group until they are cleared out.
5. To send to the group, see above directions for sending Teacher's or student's screen, and press "Group #".

**Re-programming the F-Keys:**

1. Press "Program".
2. Press "F-Key" you want to re-program.
3. Press the function you want to start ("From", "KB").
4. Press the function you want to go to ("All", "Master"). If you choose the "From" and "All" command, choose the time you want to view the student's screen in seconds. 5-10 seconds is usually enough.
5. Press "Enter".
6. Press "Program".

**Note: The "Print" and "Audio" keys do nothing in your setup. Don't use them—they don't work.**